



sideKICK too User Manual

sideKICK too User Manual

The ELC sideKICK too is a 30-memory playback panel with terminal connections. The 30 memories can be stored under 20 button playbacks and 10 fader playbacks.

The sideKICK too provides a simple to use DMX scene capture and playback of memories, each of which can be a single lighting state (up to 512 channels) or a chaser with individual period and crossfade times.

The desk is fitted with DMX in/out and a programmable DMX merger. It is ideal as a stand alone control, a backup desk, and it can be used to control other software applications, such as GrandMA OnPC.

Features

- Captures data from DMX data signal
- 30 memories of 512 DMX channels, individually recalled by a push button
- Each memory can be a scene or a chase (total desk capacity is 126 chase steps)
- Stores chaser step length and times
- Master up/down fade buttons controls lighting states from 0% to 200%
- AC612XU editor freeware provides programming functions

Functional overview

The ELC sideKICK too has a DMX input, a DMX output and a built-in merger. The merger has operating modes like HTP/LTP and Priority. The memories are captured from the DMX input and all have 512 channels. In addition to the memories, there is a master intensity control that runs from 0% to 200%. The master is controlled by the Up and Down keys. The master Up/Down can also be set up as speed control.

The sideKICK too is powered through the USB connector, either via the supplied USB power adapter or by being connected to a computer. The USB connector is also used for future software upgrades and the AC612XU Editor software.

The AC612XU Editor software – available for download on the ELC website (www.elclighting.com) – can be used to preprogram the sideKICK too's memory. With the AC612XU Editor software it is possible to create memories for each button or fader with multiple steps (device total of 126). A USB connection is required to import or export the memories to and from the device.

This product may only be used for
controlling dimmers and moving lights.
Using the product outside of these specifications
will remove all responsibility from the supplier.

Setup mode

Changing operating modes

The operating mode of the sideKICK too can be changed by entering Setup mode. Setup mode allows you to change individual settings for the operating modes (e.g. merger mode, memory handling).

To enter setup mode, follow these steps:

- Press and hold the Store button
- Press and hold the Up button
- Wait for approximately 10 seconds for the LEDs to start flashing (the Up and Store LEDs remain on)
- The settings can now be changed, as described in the following sections
- When no button has been pressed for about 10 seconds, the unit will timeout of the setup mode and will store the current settings and go back to normal operation.

Merger mode

Key		Function
Up	Down	
○	○	HTP merge
☼	○	LTP merge
○	☼	Priority merge (memories of the unit are disabled if a valid DMX signal is on the input)

Store disable

If the LED on the store button is on, then storing new memories is disabled.

Startup memory (at power on)

Key				Function	Key				Function
1	2	3	4		1	2	3	4	
○	○	○	○	No startup memory					
☀	○	○	○	Memory 1	☀	☀	☀	○	Memory 7
○	☀	○	○	Memory 2	○	○	○	☀	Memory 8
☀	☀	○	○	Memory 3	☀	○	○	☀	Memory 9
○	○	☀	○	Memory 4	○	☀	○	☀	Memory 10
☀	○	☀	○	Memory 5	☀	☀	○	☀	Memory 11
○	☀	☀	○	Memory 6	○	○	☀	☀	Memory 12

Memory mode

Key		Function (Memory Hold)
5	6	
○	○	Swap → only one memory active
☀	○	Toggle → switch memory on/off
○	☀	Flash → temporary memory

Fade tables (see Creating memories)

Key		Fade time tables				
7	8	Table	Fade time 1	Fade time 2	Fade time 3	Fade time 4
○	○	1	0 seconds	1 second	2 seconds	5 seconds
☀	○	2	0 seconds	5 seconds	10 seconds	15 seconds
○	☀	3	1 second	10 seconds	15 seconds	20 seconds
☀	☀	4	5 seconds	10 seconds	20 seconds	30 seconds

Up/down mode

Key		Function
9	10	
○	○	Up/Down buttons control intensity
☀	○	Up/Down buttons control speed

Master / Slave / Operation mode

Key				Function
11	12	13	14	
○	○	○	○	Normal standalone operation
☼	○	○	○	Device is master of a system (contains memories)
○	☼	○	○	Slave in a system
☼	☼	○	○	Last slave in a system (RDM signal is blocked)
○	○	☼	○	DMX remote wing with offset 1
☼	○	☼	○	DMX remote wing with offset 51
○	☼	☼	○	DMX remote wing with offset 101
☼	☼	☼	○	DMX remote wing with offset 151

In Master/Slave mode, the master device should be first in the DMX line. The slaves are then daisy-chained to the master. In daisy-chaining, the output of the master device is connected to the input of the slave device. The output of the slave device can then be connected to the input of another slave device, and so on. The master device communicates with the slave devices through RDM (bidirectional DMX). If devices after the last slave device are not handling the RDM signal correctly, the last slave should be programmed as slave-last (this will block the RDM signal).

Operation

Creating memories (with faders)

To store a memory (captured from the DMX input) into one of the ten faders, follow the next steps:

- Press the Store button (the button will now start flashing, indicating that no fader has been selected). The built-in merger is now disabled and will pass through the DMX input signal.
- Create the required memory by the external DMX source
- Move the chosen fader to it's full position. The Store LED will now be on. (If the fader is already at the full position, move it down first and back up.)
- Selecting the same fader again will undo the selection and a different fader can be selected.
- Press the Store button to save the memory

Creating memories (with buttons)

To store a memory (captured from the DMX input) into one of the 30 buttons, follow the next steps:

- Press the store button (the button will now start flashing, indicating that no button has been selected). The built-in merger is now disabled and will pass through the DMX input signal.
- Create the required memory by the external DMX source
- Press the chosen memory button (1-30) – the Store LED is now on
- Set the fade time for the memory, by using the next table:

Key		Function (depends on fade time table)
Up	Down	
○	○	Fade time 1 (0/0/1/5 seconds)
☀	○	Fade time 2 (1/5/10/10 seconds)
○	☀	Fade time 3 (2/10/15/20 seconds)
☀	☀	Fade time 4 (5/15/20/30 seconds)

- Pressing the same button again will disable the selection
- Press the Store button to save the memory

To set the blackout/fadeout timing, follow the steps above – only instead of selecting one of the memory buttons, select the blackout button (next to the Store button).

Normal operation

In normal operation, you can recall memories using the faders or buttons.

The master intensity control (0% to 200%) is handled by the Up and Down buttons.

If both the Up and Down button LEDs are off, the master control is at 100%. If the Up button LED is on, the master control is above 100%. With the Down button LED on, the master control is below 100%. To set the master control back to 100%, press the Up and Down buttons simultaneously.

DMX remote wing operation

In DMX remote wing operation, all buttons and faders are sent as separate DMX channels. Buttons 1 to 30 are sent as channels 1 to 30. The Down button is sent as channel 31, the Up button as channel 32 and the Store button as channel 33. The faders are sent as channels 41 to 50. The DMX merge is set to HTP. Multiple sideKICK too devices can be used when setting the offset to 51, 101 or 151.

Please note: To get back into the Setup menu, follow the next steps:


- Switch off the device (unplug the USB cable)
- Press and hold both the Up and Down key
- Switch on the device (plug in the USB cable)

The device will now start up in Setup mode (indicated by the blinking LED's).

AC612XU Editor software (PC/Mac)

The AC612XU Editor software – available on the ELC website (www.elclighting.com) – can be used to create the memories. Each memory can have multiple steps and each step (from a total of 126) can have it's own crossfade time and duration.

Main window



File menu

- New → clear all memories and settings
- Open → open a previously created setup of memories and settings
- Save → store all memories & settings to disk
- Save as → store all memories & settings to disk (different file name)
- Exit → quit the application

Device menu

- View DMX → reopen the DMX window if it is not displayed
- Merge DMX → if checked the DMX output of the sideKICK too will be a HTP merge of the device DMX and the AC612XU Editor
- Grab DMX → load the device DMX data into the AC612XU Editor
- Settings → open the Settings window (explained below)
- Import → load memories & settings from the device into the Editor
- Export → store memories & settings from the Editor onto the device

Edit menu

- Record Step → opens the Record window to update the current step or store the information to a different/new step
- Add Step → similar to Record step but the step number is incremented
- Delete Step → removes the currently selected step
- Clear Editor → sets all channels in the AC612XU Editor to 0%
- Clear Memory → deletes all steps in the memory

View mode

In this menu you can select the naming of the cue list tabs to match your device.

Help menu

- About → show the software version

Using the AC612XU Editor

The Editor can be used either with the keyboard (command line) or the mouse.

Using the keyboard (command line)

By typing in the required channels and setting the levels you can create a scene.

The keys used are:

- 0, 1, 2, 3, 4, 5, 6, 7, 8 and 9 → digit entry
- +, -
- t (or / on Windows keypad) → through
- ' (or * on Windows keypad) → at
- f (or . on Windows keypad) → full
- Enter → activate the command


Examples:

- **1 t 12 ' 50** → 1 → 12 @ 50 (channel 1 through 12 at 50%)
- **1 + 3 f** → 1 + 3 full (channel 1 and 3 at 100%)

Using the mouse

Select a channel by left clicking it in the AC612XU Editor window. The channel will be highlighted in yellow to indicate that it is selected. To select multiple channels hold the Ctrl key when left clicking channels. To change the value, click and hold the left mouse button and drag the channel value up and down. Dragging with the right mouse button will change the value at a slower pace for more precision.

Recording a step



Select Record Step from the Device menu (or press R or A) to bring up the Record Step window.

Step number indicates the number of the step (maximum of 126 memories for the device).


Crossfade Time sets the fade time for the step.

Duration sets how long the step will last (time before the next step is activated).

Setting the duration to STOP will end the playback of the memory at that step. If no step in a memory has a STOP programmed, then the memory will loop through all steps.

Device settings

The Device Settings window provides an easy menu to change settings like merge mode, store disable, etc. All of these functions are described in the Setup Mode section of this manual.



sideKICK too Interface software

To use the sideKICK too with offline software, please download the sidekick too Interface software from the Download Center of the ELC Lighting website (www.elclighting.com).

The sideKICK Interface software converts the sideKICK too (or AC612XU) into a DMX to ArtNet converter. All DMX generated by the device (playback) and the DMX input are converted to ArtNet and sent to the IP address with the universe number as selected.

For grandma(2) onPC in combination with sideKICK too.

Firmware upgrading

The USB Update software – available in the download center of the ELC website (www.elclighting.com) – is used to upgrade the firmware of the sideKICK too. The latest firmware for your device can also be downloaded from there.

Follow the next steps to execute a firmware upgrade:

- Power off the device
- Press and hold the Store button
- Connect the device to the computer using a USB cable
- Windows users might need to install the USB drivers located in the downloaded .zip-file
- Start the USB Update program
- Press Update
- Select the downloaded firmware
- When the update is completed;
 - Exit the program
 - Disconnect the USB cable
- Power up the device

PLEASE NOTE: Previously created memories might get lost during the update.

Technical specifications

Power:	5V 200mA USB-type B
Dimensions:	250 x 200 x 35 mm
Weight:	1.4 kg

General safety instructions

Read all instructions - especially the safety requirements - in the user manual before use. Save these instructions - the safety and operating instructions should be retained for future reference. Carefully follow all instructions.

Cleaning

Disconnect all connected supply and signal cables before cleaning the unit. Clean with a dry cloth. Do not use any liquids or aerosols on the unit.

Usage

Do not use the unit near water or moisture. - Do not block any ventilation openings, they are necessary for the essential airflow within the unit and protect it against overheating. - Install in accordance with the manufacturer's instructions. - Do not insert any objects through the ventilation slots of the unit, as these could come in contact with live parts or could cause short circuits. This could cause electric shock and/or fire. - Do not install near any heat sources such as radiators, stoves or other apparatus (including amplifiers) that produce heat. - Unplug this apparatus during lightning storms or when unused for long periods of time. Do not place the unit on unstable surfaces.

Servicing

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way such as; damage to the power supply cord or plug, spillage of liquids, objects falling into the apparatus, exposure to rain or moisture, abnormal operation or falling damage. In all of the previous conditions, disconnect the main plug immediately and call your distributor or technical support!

WARNING

**TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,
DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE**

Declaration of Conformity

We,

Manufacturers name: ELC lighting b.v.

Manufacturers address: Weerijis 8
5422 WV Gemert
the Netherlands

Herewith take the full responsibility to confirm that the product

Product Category: Lighting control equipment

Name of product: ELC-SDK2

Which refer to this declaration are manufactured in the Netherlands and complies with the following product specifications and harmonized standards:

Safety: LVD (Low Voltage Directive) 2014/35/EU, EN62368-1

EMC: 2014/30/EG, EN55032

ROHS (II): 2011/65/EU

With the presumption that the equipment is used and connected according to the manual, supplied with the equipment. All signal input- and output connections must be shielded and the shielding must be connected to the ground of the corresponding plug.

Gemert, February 16, 2018

ing. Joost van Eenbergen

