



Installing the AC612 driver


- Open the folder AC612 usb driver
- Locate the file **elcdmx512 (.inf)**



- Right click the file
- And select **Install**



- Click **Yes** to confirm



- Click **Install** to finish installation of the AC612 driver

The installation will report success and the AC612 is can now be used by the AC612 editor.

